

Bungee Belt Assembly Instructions

- 1) Straighten out the belt in front of you on a table so that the Velcro is on the left end and the buckle is on the right end.
- 2) The loop of rope should be facing upwards on the left and the buckle will be facing upwards on the right.
There is a rectangular plastic belt hook that slides up and down between the loop of rope and the buckle. Slide it towards the middle and disregard it for the moment.
- 3) Take the Velcro end and pass it through the first part (left side) of the buckle so that the loop comes through too.
Note: You may have to pull on the Velcro end firmly to get the loop of rope through the buckle but don't worry, it will pass through the buckle.
- 4) Then take the Velcro end again and pass it through the second part of the buckle (right side), the loop should come through too.
- 5) You're done! The buckle can be used to adjust the length and the Velcro fastens around the rectangular plastic belt hook.